

Accessory Preparation Checklist - M Series Printer

INTRODUCTION

This document lists the actions that must be taken to unbox and organize your accessories before familiarization training. Please make sure all of the steps below are completed before your scheduled training.

1. Unbox resin dispensing gun.
 - a. Plug in extra battery to charge.
2. Unwrap blue mats and tape down to tables/workspace with painter's tape.
3. Line the inside of the compressed air cleaning cabinet (CACC) with blue mats.
 - a. Install gloves on CACC.




Cox dual drive dispenser

4. Unbox IPA and acetone bottles.
 - a. Fill each bottle up to marked line with the appropriate solvent.
 - b. Place remainder of the solvent in the flammables cabinet for quick access.
5. Unbox resin and place in storage cabinet.
 - a. Check to ensure mixing tips arrived.
6. Unwrap orbital shaker and connect to power.
 - a. Cut a blue mat to size and add to top of orbital shaker to absorb spillage.



Compressed air cleaning cabinet



Orbital shaker



Pour stand

7. Ensure the following items are present:

a. Two baking sheets



b. Nitrile gloves



c. Blue towels



d. Aluminum foil



8. Cover both baking sheets with a layer of foil.
9. Unbox the cassette pour stand and set on bench.

10. Place the following items by the cassette pour stand:

a. Funnels



b. Waste cups



c. Funnel strainers



d. Spatula



e. Blue towels



11. Use separate waste cups as holders for small, medium, and large swabs.
12. Place the following items in another cup.

a. Yellow scraper



b. X-Acto knife



c. Wire cutters



13. Unwrap and place the following items by the oven:

a. Silicone mat



b. Heat resistant gloves



c. Baking tray

